

The Great Lakes - St. Lawrence Seaway System *Le réseau Grands Lacs - Voie maritime du Saint-Laurent*

2019 – Notice to Shipping #1 MAISONNEUVE REGION MONTRÉAL / LAKE ONTARIO SECTION

Final Mooring Position Tolerances for Full Sized Vessels Using HFM

Mariners are advised that a <u>two metres tolerance</u> (acceptable zone) on final mooring positions is in effect at locks 1 through 4 in the MLO section, for full sized vessels (those with an overall length of 222.5m or greater) using Hands Free Mooring (HFM).

Downbound: Full sized vessels will be directed to go to the stop symbol (0m). Vessels will be processed with HFM units if they stop between the stop symbol (0m) and 2m past the stop symbol (-2m).

Upbound: Full sized vessels will be directed to go to 1m past the stop (-1m). Vessels will be processed with HFM units if they stop between 1m past the stop symbol (-1m) and 3m past the stop symbol (-3m).

Vessel Direction	Final Mooring Position Zone	
	From	То
Downbound	0m (stop symbol)	-2m (2m past stop)
Upbound	-1m (1m past stop)	-3m (3m past stop)

Note: A full sized vessel being processed with HFM and stopping within the tolerances specified above will not be subject to violation (Clause 40.(1) of the Seaway Practices and Procedures).

Maisonneuve Region

March 20th, 2019

The St. Lawrence Seaway Management Corporation Corporation de Gestion de la Voie Maritime du Saint-Laurent

Région Maisonneuve 151, rue de l'Écluse St-Lambert, Québec J4R 2V6 Tél: (450) 672-4115 Fax: (450) 672-8493 Niagara Region 508 Glendale Avenue P.O. Box 370 St-Catharines, Ontario L2R 6V8

Tél: (905) 641-1932 Fax: (905) 641-5721