



## 2025 - NOTICE TO SHIPPING #24

### MAISONNEUVE REGION MONTREAL / LAKE ONTARIO SECTION

#### **New Access Procedure at Iroquois Lock**

To standardize security procedures at Canadian locks, a new access procedure will be implemented at Iroquois Lock on **July 15, 2025**.

A turnstile and an access control area for vehicles composed of two motorized barriers, will now replace the single motorized barrier at the main entrance.

#### **Entry Access Protocol**

##### **- Driver and vehicle:**

- Vehicle requires identification markings on both sides;
- Vehicle and driver only to proceed into control area (one vehicle at a time);
- Press intercom button, scan access card at reader, explain reason of visit and show pass;
- Enter control area and open all doors and trunk;
- Scan access card at reader (first barrier must be fully closed);
- Enter lock when gate is open.

##### **- Passenger:**

- All passengers must access through the turnstile;
- One person at a time: press intercom button, scan access card at reader, explain reason of visit, show pass and enter lock when turnstile is unlocked;
- Arrive at the turnstile 15 minutes early (before ship reaches Limit of Approach 2 (L/A 2)).

#### **Exit Protocol**

##### **- Driver and vehicle:**

- Vehicle and driver only to proceed into control area (one vehicle at a time);
- Press intercom button and signal exit;
- Scan access card at reader and enter control area;
- Scan access card at reader in control area (first barrier must be fully closed);
- Exit when gate is open.



**The Great Lakes - St. Lawrence Seaway System**  
***Le réseau Grands Lacs - Voie maritime du Saint-Laurent***

---

**- Passenger:**

- Press intercom button at turnstile and signal exit;
- Scan access card at reader and exit.

The access procedure is explained in the video available at the following link:

[Access to a Lock through the SAS or turnstile.](#)

Thank you for your cooperation.

July 14, 2025